

Lab-02 Report

st122246

June 21, 2022

1 Q1: Show Image

```
1 import cv2 as cv
2
3 IMAGE_FILE = ".../.../.../Data/sample.jpg"
4
5 if __name__ == "__main__":
6     img = cv.imread(IMAGE_FILE)
7     if img is None:
8         print("Error: No image to show")
9
10    cv.imshow("Input image", img)
11
12    # Wait up to 5s for a key press
13    cv.waitKey(5000)
14
```

2 Q2: Show Video

```
1 import sys
2 import cv2 as cv
3
4 VIDEO_FILE = ".../.../.../Data/robot.mp4"
5 ROTATE = False
6
7 if __name__ == "__main__":
8     key = -1
9
```

Figure 1: Q1: Show Image





Figure 2: Q2: Show Video




```

10 # Open video file
11 videoCapture = cv.VideoCapture(VIDEO_FILE)
12 height = videoCapture.get(cv.CAP_PROP_FRAME_HEIGHT)
13 width = videoCapture.get(cv.CAP_PROP_FRAME_WIDTH)
14
15 if not videoCapture.isOpened():
16     print("ERROR! Unable to open \
17 video file {}".format(VIDEO_FILE))
18     sys.exit()
19
20 # Capture loop
21 while key != ord(' '):
22     # Get the next frame
23     _, matFrameCapture = videoCapture.read()
24     if matFrameCapture is None:
25         # End of video
26         break
27
28     # Rotate Video
29     if ROTATE:
30         # Rotate 180 degree and put \
31         image to matFrameDisplay
32         _, matFrameDisplay = cv.rotate(
33             matFrameCapture,
34             cv.ROTATE_180)
35     else:
36         matFrameDisplay = matFrameCapture
37
38     # Resize the frame
39     ratio = 480.0 / height
40     down_height = int(height * ratio)
41     down_width = int(width * ratio)
42     matFrameDisplay = cv.resize(matFrameDisplay,
43                                 (down_width,
44                                  down_height),
45                                 ratio, ratio, cv.
46                                 INTER_LINEAR)
47
48     # Display the frame
49     cv.imshow(VIDEO_FILE, matFrameDisplay)
50
51     key = cv.waitKey(1)
52
53     if key == 27:
54         break
55
56 cv.destroyAllWindows()

```

Figure 3: Q3: Show Video With Description



48 key = cv.waitKey(30)

3 Q3: In-lab exercise 1

1. Use `waitKey()` to wait for the user to press `'space'` to advance to the next frame or `'q'` to quit. Check the documentation for `waitKey()`, change the delay parameter to 0 for an infinite wait, and perform the necessary action on a `'spacebar'` or `'q'` key.
2. Display the full 1080p or 720p frame from the video without making the display window too big for your desktop. Take a look at the documentation for `namedWindow()` and figure out which flags you should use to set up your display window to be resizable but keep the aspect ratio and display the expanded GUI.
3. Next we probably want to give the user some useful information. Check out the documentation for `displayOverlay()` and add some explanatory information for the user about frame number, total frames, and user control actions.
4. Last little detail: currently, if the user closes the window, the program doesn't exit. Modify your program to exit when image display window is closed.

```

1 import sys
2 import cv2 as cv
3
4 VIDEO_FILE = ".../.../.../Data/robot.mp4"
5 ROTATE = False
6
7 if __name__ == "__main__":
8     key = ord(" ")
9
10    # Open video file
11    videoCapture = cv.VideoCapture(VIDEO_FILE)
12    height = videoCapture.get(cv.CAP_PROP_FRAME_HEIGHT)
13    width = videoCapture.get(cv.CAP_PROP_FRAME_WIDTH)
14    totalFrameNum = int(videoCapture.get(cv.
15        CAP_PROP_FRAME_COUNT))
16    if not videoCapture.isOpened():
17        print("ERROR! Unable to open video file {}".format(
18            VIDEO_FILE))
19        sys.exit()
20
21    # Capture loop
22    while True:
23        # Get the next frame when press <space>
24        if key == ord(" "):
25            _, matFrameCapture = videoCapture.read()
26            currentFrameNum = int(videoCapture.get(cv.
27                CAP_PROP_POS_FRAMES))
28            if matFrameCapture is None:
29                # End of video
30                break
31
32            # Rotate Video
33            if ROTATE:
34                # Rotate 180 degree and put image to
35                matFrameDisplay
36                matFrameDisplay = cv.rotate(matFrameCapture, cv
37                    .ROTATE_180)
38            else:
39                matFrameDisplay = matFrameCapture
40
41            # Resize the frame

```

```

37     height_ratio = 768.0 / height
38     width_ratio = 1366.0 / width
39     down_height = int(height * height_ratio)
40     down_width = int(width * width_ratio)
41     matFrameDisplay = cv.resize(matFrameDisplay,
42         (down_width, down_height),
43         width_ratio, height_ratio,
44         cv.INTER_LINEAR)
45
46     # 1366p x 768p frame display in resizeable , keep
47     # aspect ratio , and show expended GUI
48     cv.namedWindow("ROBOT.MP4", flags=cv.
49     WINDOW_NORMAL | cv.WINDOW_KEEPRATIO | cv.
50     WINDOW_GULEXPANDED)
51
52     # Display the frame
53     cv.imshow("ROBOT.MP4", matFrameDisplay)
54
55     # Display overlay explanatory information
56     explanatory_info = f"{currentFrameNum} / {totalFrameNum} \
57             f" frames. Press <space> for next frame.
58             Press <q> to quit."
59     cv.displayOverlay("ROBOT.MP4", explanatory_info)
60
61     # Quit when press <q>
62     if key == ord('q'):
63         break
64
65     # Exit program on window close
66     if cv.getWindowProperty("ROBOT.MP4", cv.
67     WND_PROP_VISIBLE) != 1:
68         break
69
70     key = cv.pollKey()
71     cv.destroyAllWindows()

```

4 Q4: In-lab exercise 2

Figure 4: Q4: Select 4 Points




Figure 5: Q4: Estimated Homography

```
Run: main <
      /usr/bin/python3.10 /mnt/ntfs/Data/code/CV/computer_vision/Labs/Lab02-Homographies/04-FourPointsHomography/calibrate_homography_using_opencv_python/main.py
      Video file: ../../Data/robot.mp4
      Calibration file: robot_calibration.yaml
      Capture Point 0: [664. 593.]
      Capture Point 1: [1088. 635.]
      Capture Point 2: [925. 851.]
      Capture Point 3: [359. 762.]
      Reals Point0: [800. 800.]
      Reals Point1: [1000. 800.]
      Reals Point2: [1000. 1000.]
      Reals Point3: [800. 1000.]
      Estimated Homography Matrix:
      [[-3.13733912e-01 -4.12078341e+00  1.76834332e+03]
      [ 4.65985214e-01 -4.90948811e+00  1.71836463e+03]
      [ 3.05885275e-04 -3.89132445e-03  1.00000000e+00]]
```

Figure 6: Q4: Warped Image





Figure 7: Q4: Warped Image and Perform Optical Flow



```
1 import sys
2 import cv2 as cv
3 import numpy as np
4 from os.path import exists
5
6 point = (-1, -1)
7 pts = []
8 var = 0
9 drag = 0
10 mat_final = np.array([])
11 mat_result = np.array([])
12
13 feature_params = dict(
14     maxCorners=100,
15     qualityLevel=0.3,
16     minDistance=7,
17     blockSize=7
18 )
19 lk_params = dict(
20     winSize=(15, 15),
21     maxLevel=2,
22     criteria=(cv.TERM_CRITERIA_EPS | cv.
23     TERM_CRITERIA_COUNT, 10, 0.03)
24 )
25 color = np.random.randint(0, 255, (100, 3))
26 VIDEO_FILE = "../Data/robot.mp4"
27 ROTATE = False
28 CALIBRATION_FILE = "calibration.yml"
```

```

29     CALIBRATE = False
30
31
32     def draw_circle_and_line(x, y):
33         global point, pts, mat_result
34         mat_result = mat_final.copy()
35         point = (x, y)
36
37         if var >= 1:
38             cv.line(mat_result, pts[var - 1], point, (0, 255,
39             0, 255), 2)
40             cv.circle(mat_result, point, 2, (0, 255, 0), -1, 8,
41             0)
42             cv.imshow("Source", mat_result)
43
44     def open_video(file_name):
45         video_capture = cv.VideoCapture(file_name)
46         if not video_capture.isOpened():
47             print("ERROR! Unable to open input video file",
48             VIDEO_FILE)
49             sys.exit('Unable to open input video file')
50
51         width = video_capture.get(cv.CAP_PROP_FRAME_WIDTH)
52         height = video_capture.get(cv.CAP_PROP_FRAME_HEIGHT)
53
54         return video_capture, width, height, ratio, dim
55
56
57     def mouse_handler(event, x, y, flags, param):
58         global point, pts, var, drag, mat_final, mat_result
59
60         if var >= 4:
61             return
62
63         if event == cv.EVENT_LBUTTONDOWN:
64             drag = 1
65             draw_circle_and_line(x, y)

```

```

66
67     if event == cv.EVENT_LBUTTONDOWN and drag:
68         drag = 0
69         pts.append(point)
70         var += 1
71         mat_final = mat_result.copy()
72
73         if var >= 4:
74             cv.line(mat_final, pts[0], pts[3], (0, 255, 0,
75                                         255), 2)
75             cv.fillConvexPoly(mat_final, np.array(pts,
76                                         dtype=np.int32), (0, 120, 0, 20))
76             cv.imshow("Source", mat_final)
77
78         if drag:
79             draw_circle_and_line(x, y)
80
81
82     def calibrate():
83         global mat_final, mat_result, var, CALIBRATE
84         CALIBRATE = True
85
86         mat_pause_screen = np.array([])
87         mat_frame_capture = np.array([])
88         key = -1
89
90         # _____ [STEP 1: Make video capture
91         # from file] _____
91         # Open video file
92         video_capture, width, height, ratio, dim =
93         open_video(VIDEO_FILE)
94
95         # Capture loop
96         while key < 0:
97             # Get the next frame
98             _, mat_frame_capture = video_capture.read()
99             if mat_frame_capture is None:
100                 break
101
101             # Rotate
102             if ROTATE:

```

```

103     - , mat_frame_display = cv.rotate(
104         mat_frame_capture , cv.ROTATE_180)
105     else :
106         mat_frame_display = mat_frame_capture
107     mat_frame_display = cv.resize( mat_frame_display ,
108         dim)
109     cv.imshow("ROBOT.MP4" , mat_frame_display)
110     key = cv.waitKey(30)
111
112     # ----- [STEP 2: pause the screen
113     and show an image] -----
113     if key >= 0:
114         mat_pause_screen = mat_frame_capture
115         mat_final = mat_pause_screen .copy()
116
117     # ----- [STEP 3: use mouse handler
118     to select 4 points] -----
118     if mat_frame_capture is not None:
119         var = 0
120         pts .clear()
121         cv.namedWindow(" Source" , cv.WINDOW_GULNORMAL)
122         cv.setMouseCallback(" Source" , mouse_handler)
123         cv.imshow(" Source" , mat_pause_screen)
124         cv.waitKey(0)
125         cv.destroyWindow(" Source")
126
127     if len(pts) == 4:
128         src = np.array(pts).astype(np.float32)
129         for i , item in enumerate(src):
130             print(f"Capture Point {i}: {item}")
131
132         reals = np.array([
133             (800, 800),
134             (1000, 800),
135             (1000, 1000),
136             (800, 1000)
137         ] , dtype=np.float32)
138         for i , item in enumerate(reals):
139             print(f"Reals Point{i}: {item}")

```

```

140
141      # _____ [STEP 4: Calculate
142      Homography] _____
143      homography_matrix = cv.getPerspectiveTransform(
144      src, reals)
145      print("\nEstimated Homography Matrix: ")
146      print(homography_matrix)
147
148      # _____ [STEP 5: Save
149      Homography to file] _____
150      cv_file = cv.FileStorage(CALIBRATION_FILE, cv.
151      FILE_STORAGE_WRITE)
152      cv_file.write("H", homography_matrix)
153      cv_file.release()
154
155      # _____ [STEP 6: Warp Inverse
156      Bi-linear Interpolation] _____
157      h, w, ch = mat_pause_screen.shape
158      mat_result_frame = cv.warpPerspective(
159      mat_pause_screen, homography_matrix,
160              (mat_pause_screen[1],
161               mat_pause_screen[0]), cv.INTER_LINEAR)
162
163      mat_source_frame = cv.resize(mat_pause_screen,
164      dim)
165      cv.imshow("Source", mat_source_frame)
166
167      mat_result_frame = cv.resize(mat_result_frame,
168      dim)
169      cv.imshow("Result", mat_result_frame)
170
171      cv.waitKey(0)
172      else:
173          print("Required 4 points to calculate
174          Homography!")
175      else:
176          print("No pause before end of video finish.
177          Exiting.")
178
179      def show_source_result_with_optical_flow():

```

```

170     cv_file = cv.FileStorage(CALIBRATION_FILE, cv.
171                             FILE_STORAGE_READ)
172     homography_matrix = cv_file.getNode("H").mat()
173     cv_file.release()
174
175     # Open video file
176     video_capture, width, height, ratio, dim =
177     open_video(VIDEO_FILE)
178     _, frame = video_capture.read()
179     old_frame_source = frame
180     old_frame_result = cv.warpPerspective(frame,
181                                         homography_matrix,
182                                         (frame.shape[1], frame.shape[0]),
183                                         cv.INTER_LINEAR)
184
185     old_gray_source = cv.cvtColor(old_frame_source, cv.
186                                   COLOR_BGR2GRAY)
187     old_gray_result = cv.cvtColor(old_frame_result, cv.
188                                   COLOR_BGR2GRAY)
189
190     p0_source = cv.goodFeaturesToTrack(old_gray_source,
191                                       mask=None, **feature_params)
192     p0_result = cv.goodFeaturesToTrack(old_gray_result,
193                                       mask=None, **feature_params)
194
195     mask_source = np.zeros_like(old_frame_source)
196     mask_result = np.zeros_like(old_gray_result)
197
198     while True:
199         ret, frame = video_capture.read()
200         if not ret:
201             print("No frames grabbed!")
202             break
203
204         frame_source = frame
205         frame_result = cv.warpPerspective(frame,
206                                         homography_matrix,
207                                         (frame.shape[1], frame.shape[0]),
208                                         cv.INTER_LINEAR)
209
210         frame_gray_source = cv.cvtColor(frame_source, cv.
211                                       COLOR_BGR2GRAY)
212         frame_gray_result = cv.cvtColor(frame_result, cv.

```

```

        COLOR_BGR2GRAY)
200
201     p1_source, st_source, err_source = cv.
202     calcOpticalFlowPyrLK(old_gray_source,
203                           frame_gray_source, p0_source, None,
204                           **lk_params)
205     p1_result, st_result, err_result = cv.
206     calcOpticalFlowPyrLK(old_gray_result,
207                           frame_gray_result, p0_result, None,
208                           **lk_params)
209
210     if p1_source is not None and p1_result is not
211     None:
212         good_new_source = p1_source[st_source == 1]
213         good_old_source = p0_source[st_source == 1]
214         good_new_result = p1_result[st_result == 1]
215         good_old_result = p1_result[st_result == 1]
216
217         for i, (new_source, old_source, new_result,
218                 old_result) in enumerate(zip(good_new_source,
219                                               good_old_source,
220                                               good_new_result,
221                                               good_old_result)):
222             a_source, b_source = new_source.ravel()
223             c_source, d_source = old_source.ravel()
224             a_result, b_result = new_result.ravel()
225             c_result, d_result = old_result.ravel()
226
227             mask_source = cv.line(mask_source, (int(
228                 a_source), int(b_source)), (int(c_source), int(
229                 d_source)),
230                               color[i].tolist(), 2)
231             mask_result = cv.line(mask_source, (int(
232                 a_result), int(b_result)), (int(c_result), int(
233                 d_result)),
234                               color[i].tolist(), 2)
235             frame_source = cv.circle(frame_source, (int(
236                 a_source), int(b_source)), 5, color[i].tolist(), -1)
237             frame_result = cv.circle(frame_result, (int(
238                 a_result), int(b_result)), 5, color[i].tolist(), -1)

```

```

226     img_source = cv.add(frame_source, mask_source)
227     img_result = cv.add(frame_result, mask_result)
228
229     img_source_resize = cv.resize(img_source, dim)
230     img_result_resize = cv.resize(img_result, dim)
231
232     cv.imshow('Source', img_source_resize)
233     cv.imshow('Result', img_result_resize)
234
235     key = cv.waitKey(30) & 0xff
236     if key == 27:
237         break
238
239     old_gray_source = frame_gray_source.copy()
240     p0_source = good_new_source.reshape(-1, 1, 2)
241     old_gray_result = frame_gray_result.copy()
242     p0_result = good_new_result.reshape(-1, 1, 2)
243
244     cv.destroyAllWindows()
245
246
247 if __name__ == "__main__":
248     VIDEO_FILE = input("Video file: ")
249     CALIBRATION_FILE = input("Calibration file: ")
250
251     if exists(CALIBRATION_FILE):
252         show_source_result_with_optical_flow()
253     else:
254         calibrate()
255         if exists(CALIBRATION_FILE):
256             show_source_result_with_optical_flow()

```

5 Q5: Exercise

1. Calculate the homography manually using the SVD of the linear system design matrix similar to the null space solution from class.
2. Compute the warped image manually using the inverse of the homography and bilinear interpolation in the input image.


Figure 8: Q5: Homography Verified by Octave

```

calibrate_homography_mn          Octave
File Edit View Navigate Code Refactor Run Tools Git Window Help
Jun 20 11:10 PM
File Browser   Current Directory: /home/awung
File Browser   Command Window
Name           -3.9878e-04 -5.1200e-04 -4.9297e-01 -2.0375e-01 3.33
-3.7439e-04 2.4117e-04 -4.8724e-01 6.5744e-01 -1.32
-4.7889e-01 1.1720e-01 8.0300e-01 8.0300e-01 4.06
-3.7389e-04 5.7202e-04 5.2640e-01 1.1224e-01 0.97
-3.7071e-04 5.2729e-04 4.9233e-01 -2.0739e-01 3.19
-4.6398e-07 4.9536e-07 6.2983e-04 1.2639e-04 7.76
7.1908e-01 6.9493e-01 -1.7456e-04 3.0789e-04 3.07
6.9493e-01 -7.1908e-01 1.8095e-04 5.4636e-04 9.95
8.6254e-04 -5.8242e-04 8.7757e-04 -3.2949e-01 -8.70
Vt =
-3.9878e-04 -3.7439e-04 -4.7889e-01 -3.7389e-04 -3.70
-3.1200e-04 2.4117e-04 1.1720e-01 -2.7202e-04 5.27
-4.9297e-01 -4.8724e-01 8.0300e-01 8.0300e-01 4.92
-2.0375e-01 6.5744e-01 8.2743e-04 6.1224e-01 -2.07
3.3396e-01 -1.3216e-01 4.0616e-04 -1.0706e-01 3.19
-7.7439e-01 3.3159e-02 8.0591e-04 -5.2640e-01 -1.85
-6.5221e-02 5.5890e-01 6.8297e-03 -2.5588e-01 7.69
-1.3707e-03 5.2430e-03 -6.9817e-01 -2.9807e-03 5.12
-2.0405e-04 -1.3975e-03 7.2361e-01 3.5692e-05 -1.60
H =
-2.0405e-04 -1.3975e-03 7.2361e-01 3.5692e-05 -1.60
ans =
-2.0405e-04 3.5692e-05 -2.4581e-08
-1.3975e-03 -1.6607e-03 -1.3418e-06
7.2361e-01 6.9820e-01 4.9472e-04
>> |
Command Window Editor

```

Figure 9: Q5: Bi-linear Interpolation



- Reuse the homography from your last run: If your program finds a file homography.yml in the working directory, it should read the homography from that file and use it to display the transformed image. For this, you will have to learn how OpenCV stores data files in YML format using the FileStorage class. When the user selects four points in a frame, output the resulting homography to the data file and re-read that file when the program starts again. This way, the user only has to do the "calibration" once.


Python Code

```

1 import sys
2 import cv2 as cv
3 import numpy as np
4 from os.path import exists

```

Figure 10: Q5: Bi-linear Interpolation with Optical Flow



```
5
6     point = (-1, -1)
7     pts = []
8     var = 0
9     drag = 0
10    mat_final = np.array([])
11    mat_result = np.array([])
12
13    feature_params = dict(
14        maxCorners=100,
15        qualityLevel=0.3,
16        minDistance=7,
17        blockSize=7
18    )
19    lk_params = dict(
20        winSize=(15, 15),
21        maxLevel=2,
22        criteria=(cv.TERM_CRITERIA_EPS | cv.
23            TERM_CRITERIA_COUNT, 10, 0.03)
24    )
25    color = np.random.randint(0, 255, (100, 3))
26    VIDEO_FILE = "../Data/robot.mp4"
27    ROTATE = False
28    CALIBRATION_FILE = "calibration.yml"
29    CALIBRATE = False
30
31
32    def draw_circle_and_line(x, y):
33        global point, pts, mat_result
```

```

34     mat_result = mat_final.copy()
35     point = (x, y)
36
37     if var >= 1:
38         cv.line(mat_result, pts[var - 1], point, (0, 255,
39             0, 255), 2)
40         cv.circle(mat_result, point, 2, (0, 255, 0), -1, 8,
41             0)
42         cv.imshow("Source", mat_result)
43
44     def open_video(file_name):
45         video_capture = cv.VideoCapture(file_name)
46         if not video_capture.isOpened():
47             print("ERROR! Unable to open input video file",
48                 VIDEO_FILE)
49             sys.exit('Unable to open input video file')
50
51         width = video_capture.get(cv.CAP_PROP_FRAME_WIDTH)
52         height = video_capture.get(cv.CAP_PROP_FRAME_HEIGHT)
53
54         return video_capture, width, height, ratio, dim
55
56
57     def mouse_handler(event, x, y, flags, param):
58         global point, pts, var, drag, mat_final, mat_result
59
60         if var >= 4:
61             return
62
63         if event == cv.EVENT_LBUTTONDOWN:
64             drag = 1
65             draw_circle_and_line(x, y)
66
67         if event == cv.EVENT_LBUTTONUP and drag:
68             drag = 0
69             pts.append(point)
70             var += 1

```

```

71         mat_final = mat_result.copy()
72
73         if var >= 4:
74             cv.line(mat_final, pts[0], pts[3], (0, 255, 0,
75 255), 2)
76             cv.fillConvexPoly(mat_final, np.array(pts,
77 dtype=np.int32), (0, 120, 0, 20))
78             cv.imshow("Source", mat_final)
79
80         if drag:
81             draw_circle_and_line(x, y)
82
83     def calc_homography(src, dst):
84
85         if len(src) != 4 or len(dst) != 4:
86             print("Four points are needed for a homography
87 ...")
88             return
89
90         print("\nCalculating homography...\n")
91
92         mat_a = np.zeros((9, 9), dtype=np.float32)
93         x_primes = dst[:, 0]
94         y_primes = dst[:, 1]
95
96         for i in range(len(src)):
97             x = src[i][0]
98             y = src[i][1]
99             x_prime = x_primes[i]
100            y_prime = y_primes[i]
101            mat_a[i * 2, 0] = -x
102            mat_a[i * 2, 1] = -y
103            mat_a[i * 2, 2] = -1
104            mat_a[i * 2, 3] = 0
105            mat_a[i * 2, 4] = 0
106            mat_a[i * 2, 5] = 0
107            mat_a[i * 2, 6] = x * x_prime
108            mat_a[i * 2, 7] = y * x_prime
109            mat_a[i * 2, 8] = x_prime

```

```

109
110     mat_a[ i * 2 + 1,  0] = 0
111     mat_a[ i * 2 + 1,  1] = 0
112     mat_a[ i * 2 + 1,  2] = 0
113     mat_a[ i * 2 + 1,  3] = -x
114     mat_a[ i * 2 + 1,  4] = -y
115     mat_a[ i * 2 + 1,  5] = -1
116     mat_a[ i * 2 + 1,  6] = x * y_prime
117     mat_a[ i * 2 + 1,  7] = y * y_prime
118     mat_a[ i * 2 + 1,  8] = y_prime
119     mat_a[8,  8] = 1
120
121     mat_w, mat_u, mat_vt = cv.SVDecomp(src=mat_a)
122     mat_h = mat_vt[8, :].reshape(3, 3)
123     return mat_h
124
125
126     def bi_linear_interpolation(img, mat_t, new_width,
127                                   new_height):
128         print("\nDoing inverse bi-linear interpolation... \
129             n")
130         # Get dimensions of original image
131         old_height, old_width, channels = img.shape
132
133         # Create new image array
134         new_img = np.zeros((new_height, new_width, channels))
135
136         for i in range(new_height):
137             for j in range(new_width):
138                 # Map the coordinates back to the original
139                 # image
140                 pnt = np.array((j, i, 1)).reshape(3, 1)
141                 l_x, l_y, z = np.matmul(np.linalg.pinv(mat_t),
142                                         pnt)
143                 y = l_y / z
144                 x = l_x / z
145
146                 # Check the inverse points lines in original
147                 # image

```

```

144         if 0 <= y < old_height -1 and 0 <= x < old_width
145             -1:
146                 # Calculate the coordinate values for 4
147                 surrounding pixels
148                     x0 = int(np.floor(x))
149                     x1 = x0 + 1
150                     y0 = int(np.floor(y))
151                     y1 = y0 + 1
152
153                     # Get the neighbouring pixel values
154                     i_a = img[y0, x0]
155                     i_b = img[y1, x0]
156                     i_c = img[y0, x1]
157                     i_d = img[y1, x1]
158
159                     # Estimate the pixel value using pixel values
160                     # of neighbors
161                     color1 = (x1 - x) * (y1 - y) * i_a
162                     color2 = (x1 - x) * (y - y0) * i_b
163                     color3 = (x - x0) * (y1 - y) * i_c
164                     color4 = (x - x0) * (y - y0) * i_d
165
166                     weighted_avg_color = (color1 + color2 +
167                     color3 + color4) / 255.0
168                     new_img[i, j] = weighted_avg_color
169
170                     return new_img
171
172
173
174
175
176                     # _____ [STEP 1: Make video capture
177                     # from file] _____
178                     # Open video file
179                     video_capture, width, height, ratio, dim =
180                     open_video(VIDEO_FILE)

```

```

179
180     # Capture loop
181     while key < 0:
182         # Get the next frame
183         _, mat_frame_capture = video_capture.read()
184         if mat_frame_capture is None:
185             break
186
187         # Rotate
188         if ROTATE:
189             _, mat_frame_display = cv.rotate(
190                 mat_frame_capture, cv.ROTATE_180)
191         else:
192             mat_frame_display = mat_frame_capture
193
194         mat_frame_display = cv.resize(mat_frame_display,
195                                       dim)
196
197         cv.imshow("ROBOT.MP4", mat_frame_display)
198         key = cv.waitKey(30)
199
200         # ----- [STEP 2: pause the screen
201         # and show an image] -----
202         if key >= 0:
203             mat_pause_screen = mat_frame_capture
204             mat_final = mat_pause_screen.copy()
205
206         # ----- [STEP 3: use mouse handler
207         # to select 4 points] -----
208         if mat_frame_capture is not None:
209             var = 0
210             pts.clear()
211             cv.namedWindow("Source", cv.WINDOW_GULNORMAL)
212             cv.setMouseCallback("Source", mouse_handler)
213             cv.imshow("Source", mat_pause_screen)
214             cv.waitKey(0)
215             cv.destroyWindow("Source")
216
217             if len(pts) == 4:
218                 src = np.array(pts).astype(np.float32)
219                 for i, item in enumerate(src):

```

```

216     print(f"Capture Point {i}: {item}")
217
218     reals = np.array([
219         (800, 800),
220         (1000, 800),
221         (1000, 1000),
222         (800, 1000)
223     ], dtype=np.float32)
224     for i, item in enumerate(reals):
225         print(f"Reals Point{i}: {item}")
226
227     # ----- [STEP 4: Calculate
228     Homography] -----
229     homography_matrix = calc_homography(src, reals)
230     print("\nEstimated Homography Matrix: ")
231     print(homography_matrix)
232
233     # ----- [STEP 5: Save
234     Homography to file] -----
235     cv_file = cv.FileStorage(CALIBRATION_FILE, cv.
236     FILESTORAGE_WRITE)
237     cv_file.write("H", homography_matrix)
238     cv_file.release()
239
240     # ----- [STEP 6: Warp Inverse
241     Bi-linear Interpolation] -----
242     h, w, ch = mat_pause_screen.shape
243     mat_result_frame = bi_linear_interpolation(
244     mat_pause_screen, homography_matrix, w, h)
245
246     mat_source_frame = cv.resize(mat_pause_screen,
247     dim)
248     cv.imshow("Source", mat_source_frame)
249
250     mat_result_frame = cv.resize(mat_result_frame,
251     dim)
252     cv.imshow("Result", mat_result_frame)
253
254     cv.waitKey(0)
255 else:
256     print("Required 4 points to calculate"

```

```

        Homography!" )
250    else:
251        print("No pause before end of video finish .
252        Exiting.")
253
254    def show_source_result_with_optical_flow():
255        cv_file = cv.FileStorage(CALIBRATION_FILE, cv.
256        FILESTORAGEREAD)
257        homography_matrix = cv_file.getNode("H").mat()
258        cv_file.release()
259
260        # Open video file
261        video_capture, width, height, ratio, dim =
262        open_video(VIDEO_FILE)
263        _, frame = video_capture.read()
264        old_frame_source = frame
265        old_frame_result = cv.warpPerspective(frame,
266        homography_matrix, (frame.shape[1], frame.shape[0]),
267        cv.INTER_LINEAR)
268
269        old_gray_source = cv.cvtColor(old_frame_source, cv.
270        COLOR_BGR2GRAY)
271        old_gray_result = cv.cvtColor(old_frame_result, cv.
272        COLOR_BGR2GRAY)
273
274        p0_source = cv.goodFeaturesToTrack(old_gray_source,
275        mask=None, **feature_params)
276        p0_result = cv.goodFeaturesToTrack(old_gray_result,
277        mask=None, **feature_params)
278
279        mask_source = np.zeros_like(old_frame_source)
280        mask_result = np.zeros_like(old_gray_result)

while True:
    ret, frame = video_capture.read()
    if not ret:
        print("No frames grabbed!")
        break
    frame_source = frame

```

```

281     frame_result = cv.warpPerspective(frame ,
282                                         homography_matrix , (frame.shape[1] , frame.shape[0]) ,
283                                         cv.INTER_LINEAR)
284
285     frame_gray_source = cv.cvtColor(frame_source , cv.
286                                     COLOR_BGR2GRAY)
287     frame_gray_result = cv.cvtColor(frame_result , cv.
288                                     COLOR_BGR2GRAY)
289
290     p1_source , st_source , err_source = cv.
291     calcOpticalFlowPyrLK(old_gray_source ,
292                           frame_gray_source , p0_source , None ,
293                           **lk_params)
294
295     p1_result , st_result , err_result = cv.
296     calcOpticalFlowPyrLK(old_gray_result ,
297                           frame_gray_result , p0_result , None ,
298                           **lk_params)
299
300
301     if p1_source is not None and p1_result is not
302     None:
303         good_new_source = p1_source[st_source == 1]
304         good_old_source = p0_source[st_source == 1]
305         good_new_result = p1_result[st_result == 1]
306         good_old_result = p1_result[st_result == 1]
307
308         for i , (new_source , old_source , new_result ,
309                  old_result) in enumerate(zip(good_new_source ,
310                                              good_old_source ,
311                                              good_new_result , good_old_result)):
312             a_source , b_source = new_source.ravel()
313             c_source , d_source = old_source.ravel()
314             a_result , b_result = new_result.ravel()
315             c_result , d_result = old_result.ravel()
316
317             mask_source = cv.line(mask_source , (int(
318                 a_source) , int(b_source)) , (int(c_source) , int(
319                 d_source)) ,
320                                         color[i].tolist() , 2)
321             mask_result = cv.line(mask_source , (int(
322                 a_result) , int(b_result)) , (int(c_result) , int(
323                 d_result)) ,
324                                         color[i].tolist() , 2)

```

```

d_result)) ,
307             color[i].tolist(), 2)
308         frame_source = cv.circle(frame_source, (int(
309             a_source), int(b_source)), 5, color[i].tolist(), -1)
310         frame_result = cv.circle(frame_result, (int(
311             a_result), int(b_result)), 5, color[i].tolist(), -1)
312
313     img_source = cv.add(frame_source, mask_source)
314     img_result = cv.add(frame_result, mask_result)
315
316     img_source_resize = cv.resize(img_source, dim)
317     img_result_resize = cv.resize(img_result, dim)
318
319     cv.imshow('Source', img_source_resize)
320     cv.imshow('Result', img_result_resize)
321
322     key = cv.waitKey(30) & 0xff
323     if key == 27:
324         break
325
326     old_gray_source = frame_gray_source.copy()
327     p0_source = good_new_source.reshape(-1, 1, 2)
328     old_gray_result = frame_gray_result.copy()
329     p0_result = good_new_result.reshape(-1, 1, 2)
330
331
332     cv.destroyAllWindows()
333
334     if __name__ == "__main__":
335         VIDEO_FILE = input("Video file: ")
336         CALIBRATION_FILE = input("Calibration file: ")
337
338         if exists(CALIBRATION_FILE):
339             show_source_result_with_optical_flow()
340         else:
341             calibrate()
342             if exists(CALIBRATION_FILE):
343                 show_source_result_with_optical_flow()

```

Octave Code

```

1 X = [ 676, 1068, 973, 328 ; 627, 668, 974, 825 ]
2
3 Xprime = [800, 1000, 1000, 800 ; 800, 800, 1000,
1000]
4
5 A = []
6
7 for iPoint = 1:size(X,2)
8     x = X(:, iPoint)
9     xprime = Xprime(:, iPoint)
10
11    coeffs = ...
12    [-x(1), -x(2), -1, 0, 0, 0, xprime(1)*x(1), xprime
13    (1)*x(2), xprime(1)]
14
15    A = [A ; coeffs]
16
17    coeffs = ...
18    [0, 0, 0, -x(1), -x(2), -1, xprime(2)*x(1), xprime
19    (2)*x(2), xprime(2)]
20
21    A = [A ; coeffs]
22 end
23
24 h = null(A)
25
26 [U, W, V] = svd(A)
27
28 Vt = V'
29
30 H = Vt(9,:)
31
32 reshape(H, 3, 3)

```